



LureWright

PRECISION MATERIALS FOR LURE MAKERS



Junebug Ribbon Tail — Chartreuse Tail

Worm · 2 parts

Body 6 OZ · MEDIUM BLEND

Junebug	Shoot the body around the finished chartreuse tail placed in the full worm mold.	Medium base
Shoot at		330°F
Mold	4.75" Ribbon Tail Worm — 2 Cavity (95221)	Do-It

MAKE JUNEBUG · PER 8 OZ

Crystal Inject		8 oz
Crystal Color	Junebug	20 drops
Crystal Spark	Red .015	1/4 tsp

Ribbon Tail 2 OZ · SOFT BLEND

Chartreuse Pepper	Shoot and fully set the chartreuse ribbon tails before transferring them to the worm mold.	Soft base
Shoot at		330°F
Mold	4.75" Ribbon Tail Tail — 2 Cavity (95017)	

MAKE CHARTREUSE PEPPER · PER 8 OZ

Crystal Inject		8 oz
Crystal Color	Chartreuse	16 drops
Crystal Spark	Black .008	1/4 tsp



LureWright

PRECISION MATERIALS FOR LURE MAKERS



Steps

- ☐ 1. Heat the Junebug and Chartreuse Pepper plastisol through full cure, then cool both into the listed 330°F shooting range.
 - ☐ 2. Shoot the Chartreuse Pepper ribbon tails in Do-It tail mold 95017 at 330°F. Let them set fully, then demold them.
 - ☐ 3. Place each finished tail into the matching cavity of Do-It worm mold 95221 and seat it fully with the joint straight.
 - ☐ 4. Shoot the Junebug body at 330°F around the seated tails. Hold pressure briefly, cool, demold, and inspect the tail bond.
-

Keep each finished tail seated squarely in the full mold before injecting the body. Inspect the first pair for a straight joint, complete fill, and a sound bond.