



LureWright

PRECISION MATERIALS FOR LURE MAKERS



Smoke Silver / Pearl Shad Laminate

Swimbait · 2 parts

Back 4 OZ · MEDIUM BLEND

Smoke Silver	Load this color on the dark-side barrel of the dual injector for the Smoke Silver back.	Medium base
Shoot at		330°F
Mold	673 Swimbait — 4.75" side-injection top/bottom laminate, 5 cavity	Basstackle

MAKE SMOKE SILVER · PER 8 OZ

Crystal Inject		8 oz
Crystal Color	Smoke	12 drops
Crystal Spark	Holo Silver .008	1/4 tsp

Belly 4 OZ · MEDIUM BLEND

Pearl Shad	Load this color on the light-side barrel of the dual injector for the Pearl Shad belly.	Medium base
Shoot at		330°F
Mold	673 Swimbait — 4.75" side-injection top/bottom laminate, 5 cavity	Basstackle

MAKE PEARL SHAD · PER 8 OZ

Crystal Inject		8 oz
Crystal Color	White	12 drops
Crystal Shift	Pearl	0.15 g



LureWright

PRECISION MATERIALS FOR LURE MAKERS



Steps

- ☐ 1. Bring both fully cured colors to 330°F and load Smoke Silver and Pearl Shad into the paired barrels of a dual injector.
 - ☐ 2. Seat both injector nozzles in the side-injection port and make one smooth, simultaneous shot; hold even pressure on both plungers.
 - ☐ 3. Keep the injector orientation fixed until the cavities are packed, then let the baits cool before checking the back-to-belly split.
-

Both colors must have similar viscosity and be at the same shooting temperature for a clean laminate line. Heat each plastisol through full cure first, then cool both to 330°F. Purge the dual injector before seating it in the mold, and keep the Smoke Silver barrel aligned with the mold's back side throughout the shot.